
1(& '7 3KRQH .H\/RFDWLRQ



USING YOUR TELEPHONE

PLACE OUTSIDE CALL

- · Lift the HANDSET or press SPEAKER.
- Dial 9 and then the phone number.

PLACE INTERNAL CALL

- · Lift the HANDSET or press SPEAKER.
- · Dial the desired 4 digit extension number.

ANSWER A CALL

Lift the HANDSET or press SPEAKER key.

PLACE A CALL ON HOLD

- Press Hold key once to place caller on hold; press hold key twice to place caller on exclusive hold ("e-hold" – only your phone can pick up the call)
- To take call off hold, press the active line

Note 1: you will may need to press the **Scroll** button to view screen 1 of the programmable keys and press the line where the active line is flashing to pick up the call.

TRANSFER A CALL

- With call in progress, press TRANSFER.
- · Dial an extension or press a speed dial.
- Remain on the line to announce the call –or- hang up to release call from your phone.

TRANSFER A CALL DIRECTLY INTO VOICEMAIL

- With call in progress, press TRANSFER and dial 4000.
- When you hear the main Voicemail System menu, dial the desired extension and press #.
- Hang up; the caller is now connected to the dialed individual's Voicemail.